



## Description

Extra care must be taken to ensure that the rivets that are used are properly seated when installing semi-tubular punch rivets.

Screw the riveting tool needed for the working process into a holder in the rivet clamp as required. Hand-tighten the riveting head using the special spanners provided. Counterhold the nut using a screwdriver if necessary. Screw the corresponding counterpart to the rivet insert into the opposite side of the rivet clamp (plunger rod) with the spacing bushing and bolt, and hand-tighten.

## Benefits

- Quick changing of riveting tools
- High endurance
- High quality - Made in Germany

## Scope of delivery

- Rivet bolt / die Ø 3 mm
- Rivet bolt / die Ø 5 mm
- 4 Elastomer rings
- Spanner

## Technical data

Designed for	60 kN
Thread	M6
Suitable for	PNP 90
Manufacturer	TKR PowerTools
Made in	Germany

## Dimensions & Weight

L x W x H	19,50 cm x 12,00 cm x 4,50 cm
Weight	0,5 kg

For further questions please do not hesitate to contact us.

KAMATEC GmbH  
Im Oberen Tal 31  
74858 Aglasterhausen  
GERMANY

Tel: +49 (0) 6262 / 92 605-0  
Fax: +49 (0) 6262 / 92 605-29  
Mail: [info@kamatec.com](mailto:info@kamatec.com)  
Web: [www.kamatec.com](http://www.kamatec.com)